

# Module CAN LOCODUINO

TERM



IC2

K1

Q1

C1

RX1BF

RX0BF

TX2RTS

TX1RTS

TX0RTS

SOF

C4

K2

D1

R3

RESET

K3

IC1

C3

C5

R2

INT

SCK

MOSI

MISO

CS

RST

VIO

GND

RXCAN

TXCAN

5V

